





Step 1 – excavate the area





## Step 2 – install the underdrain





Step 3 – concrete ribbon curb









Step 5 – stabilize the area (sod & hydroseeding)

